



Toshiba Satellite M55-S135 RAM Replacement

Replace the RAM in your Toshiba Satellite.

Written By: Matthew Trinh



INTRODUCTION

This guide illustrates how to replace the RAM in your Toshiba Satellite.



TOOLS:

- [Phillips #00 Screwdriver](#) (1)



PARTS:

- [PC2700 1 GB RAM Chip](#) (1)

Step 1 — RAM





- Orient the laptop so that it is closed, faced down and has the battery facing away from you.
- Use the Phillips 00 screwdriver to remove the 7.50mm screw from the panel.

Step 2



- ⚠ Carefully remove the cover to reveal the RAM compartment.

Step 3



- Rotate the laptop 90 degrees clockwise.
- Pull back the two silver clips that hold the RAM in place.
- Gently pull the RAM out of the slot and lift up to remove the RAM from the laptop.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-20 04:46:48 PM.